

**Walt Disney Concert Hall****Glatter-Götz Orgelbau/Rosales Organ Builders**

Installed and voiced 2002/2004/2018 – 110 ranks

**GREAT – Manual II** (*unenclosed*) 5" wind

32' Violonbasse (*façade*)  
 16' Prestant (*façade*)  
 16' Violonbasse  
 16' Bourdon  
 8' Principal  
 8' Diapason á pavilion  
 8' Violoncelle  
 8' Flûte harmonique  
 8' Chimney Flute  
 8' Bourdon (*wood*)  
 5-1/3' Grand Nasard  
 4' Octave  
 4' Spire Flute  
 3-1/5' Grande Tierce  
 2-2/3' Octave Quinte  
 2' Super Octave  
 III Grande Fourniture (*2 2/3'*)  
 VIII Mixture (*2'*)  
 IV Cymbale (*1'*)  
 VII Corneta Magna (*mounted*)  
 32' Contre Basson  
 16' Basson  
 8' Basson  
 4' Basson  
 8' Trompeta de Los Angeles

**POSITIVE – Manual I** (*enclosed*) 4" wind

16' Quintaton  
 8' Principal  
 8' Unda Maris (*CC*)  
 8' Gambe  
 8' Flûte harmonique  
 8' Gedackt  
 4' Octave  
 4' Hohlflöte  
 2-2/3' Nasard  
 2' Octave  
 2' Waldflöte  
 1-3/5' Tierce  
 1-1/3' Larigot  
 IV Mixture (*1-1/3'*)  
 16' Clarinet bass (*new 2018*)  
 8' Trompette  
 8' Cromorne  
 8' Clarinet (*new 2018*)  
 8' Cor anglais  
 4' Clairon  
 Tremolo  
 16' Llamada Tuba  
 8' Llamada Tuba  
 4' Llamada Tuba  
 8' Trompeta de Los Angeles

**LLAMARADA – Manual IV** (*enclosed*) all stops 7" wind

8' Flautado grande  
 4' Octava real  
 V Compuestas (*2 2/3' - 2' - 1 3/5' - 1 1/7' - 8/9'*)  
 V Lleno fuerte (*2 2/3'*)  
 16' Contra Tromba  
 8' Tromba  
 4' Tromba Clarion  
 Tremolo  
 16' Llamada Tuba (*horizontal*)  
 8' Llamada Tuba (*horizontal*)  
 4' Llamada Tuba (*horizontal*)  
 8' Trompeta de Los Angeles (*horizontal*)

**SWELL – Manual III** (*enclosed*) 4 1/2" wind

16' Bourdon  
 8' Diapason  
 8' Flûte traversière  
 8' Bourdon  
 8' Viole de Gambe  
 8' Voix céleste (*CC*)  
 8' Voix Éolienne (*pp*)  
 8' Voix Angelique (*t.c - pp*)  
 4' Principal  
 4' Flûte octaviante  
 2-2/3' Nasard  
 2' Octavin  
 1-3/5' Tierce  
 1' Piccolo  
 III-V Plein-jeu harmonique (*2-2/3'*)  
 16' Bombarde  
 8' Trompette  
 8' Hautbois  
 8' Voix humaine  
 4' Clairon  
 Tremolo

**PEDAL -**

32' Flûte (*open wood*)  
 32' Violonbasse  
 32' Bourdon  
 16' Flûte (*ext.*)  
 16' Prestant  
 16' Violonbasse  
 16' Subbass  
 16' Bourdon (*Sw.*)  
 10-2/3' Grosse Quinte (*variable*)  
 8' Octave  
 8' Flûte  
 8' Violoncelle  
 8' Bourdon  
 4' Octave  
 4' Flûte  
 V Mixture (*5-1/3'*)  
 64' Contre Basson (*BBBBB*)  
 32' Contre Bombarde  
 32' Contre Basson  
 16' Grande Bombarde (*ext.*)  
 16' Llamada Tuba  
 16' Contra Tromba  
 16' Basson  
 16' Clarinette bass (*new 2018*)  
 8' Llamada Tuba  
 8' Trompeta de Los Angeles  
 8' Basson  
 8' Clarinet (*new 2018*)  
 4' Llamada Tuba  
 4' Trompeta de Los Angeles